

NAUTRONIC SCOREBOARD SYSTEM

Danmarksvej 1
DK-8660 Skanderborg
Tel: +45 86 51 11 66
scoreboards@nautronic.com
nautronic.com

The entire guide is subject to alterations



NAUTRONIC
SCOREBOARD SYSTEM

NAUCON-20


 *User Guide*

 *Brugervejledning*





Getting to know your Naucon-20



Time 2
The Time 2 button sets the shot clocks to 14 seconds

Start
Starts or continue countdown

Stop
Stops the countdown

Time 1
Default 24 seconds

Time 2
Default 14 seconds

Reset
Resets Time 1 (24 seconds)

↑ and ↓
Pressing one of the arrows makes the display flash. The time is changed by pressing ↑ or ↓. Confirm changes by pressing **ENTER**


Enter
Confirming changes made

Setup
To change the preset times **Time 1** and **Time 2** you start by pressing the green **RESET** button to blank the display. Then press **SETUP** followed by **Time 1** or **Time 2** to change the preset time. Display will flash and the time is changed by pressing ↑ or ↓. Confirm by pressing **ENTER**

For more information on troubleshooting and service vi



Sådan virker din Naucon-20



Time 2
Time 2 knappen sætter shot clocken til 14 sekunder

Start
Starter eller fortsætter nedtællingen

Stop
Stopper nedtællingen

Time 1
standard indstillet til 24 sekunder

Time 2
standard indstillet til 14 sekunder

Reset
Nulstiller til Time 1 (24 sekunder)

↑ og ↓
Når man trykker på en af pilene blinker cifrene på skærmen og du kan ændre tiden ved at trykke ↑ eller ↓. Tryk **ENTER** For at bekræfte indstillingerne

Enter
Bekræfter evt ændringer

Setup
Hvis du skal ændre standard indstillinger for **Time 1** og **Time 2**, skal du først trykke på den grønne **RESET** knap for at nulstille shot-clocken. Tryk på **SETUP** og derefter **Time 1** eller **Time 2** for at ændre standard indstillingerne. Cifrene på skærmen blinker og du kan nu ændre tiden ved at trykke ↑ eller ↓. Tryk **ENTER** For at bekræfte indstillingerne

ice visit nautronic.com/spareparts/naucon-1000-service

